

FLY LOCK MODE

The WiseLED Tactical NG have a fly lock setting in which the flashlight can not be turned on by accident.

Set flashlights to fly lock mode


The WiseLED Tactical NG:

To lock:

Press button 4 times within 2 seconds. When the tail light turns from orange to blue, press button again within 2 second

To unlock:

Press the button 4 times within 2 seconds.



This document can be downloaded from WiseLED's website
http://www.wiseled.com/wiseled_support_download.htm

WiseLED Aps.
Bøgebakken 15
DK - 3250 Gilleleje
Denmark

Phone +45 8888 7300
Fax +45 8888 7309
info@wiseled.com
Company registration number 27311776