



# Tactical

The world's most powerful handheld flashlight

## User guide

### Button: A

Press and release: On/ Off  
 Press and hold down: Strobe  
 Press the button 4 times within 2 seconds: The taillight turns orange.  
 Then press the button again within 2 seconds and the flashlight button is locked (use this function when traveling by plane or whenever you want to prevent the flashlight from turning on accidentally).  
 To unlock the button, press again 4 times within 2 seconds.

### Button: B

Press and release: Boost  
 Press and hold down: Continuous dimming control (loop)  
 Press and release twice: Taillight on  
 Press and release 3 times: Main and taillight on  
 Press and release 4 times: SOS continuous

### Remember button A has to be activated before button B

When you run your flashlight at maximum power for a longer period of time, it will automatically return to continuous drive mode. This prevents the flashlight from overheating, and secures you optimal battery life time. Never change taillight or remove lightline/charger with the flashlight On.

Turn the flashlight off before changing connections.

## Maintenance

Cleaning: Just wash it under running water or with a dry cloth – no chemicals needed or advised.  
 Storing: Keep your Wiseled flashlight within reach and charged – you never know when you will need it.  
 Refurbishing: If the front- or backend of the flashlight wears out over the years, you can order new backend and frontend pieces.


## Charging

(Please note: The charger cradle is optional and NOT included in the standard package)

It's advised to always keep the flashlight fully charged.  
 Charging indicator: Orange when charging  
 Blue when 90% recharged  
 Charging indicator cradle: Orange when charging  
 Blue when 90% recharged  
 Charging time: 2-3 hours.

You can either charge in the charger cradle, or directly connect the flashlight to the cable. When you use a cradle, slide in the flashlight with the front facing directly towards you. When you use the charger cable directly, align the red dot on the cable with the marker on the flashlight.

WiseLED flashlights have to be kept fully charged at all times. Our warranty won't cover flashlights that have been left uncharged for a period of 2-3 weeks and this is not to happen more than 3 times, as this will significantly deteriorate the battery. The Li-ion batteries chemistry is not able to survive longer periods without energy so if not charged with a timely interval your batteries will get less efficient and the chemistry inside will eventually give up. So therefore remember always to fully recharge your flashlight before storing it for longer periods of time.



## Specifications

- 7 LED Efficiency 2,000 Lumen
- LED lifetime + 50,000 hours
- Battery: Rechargeable Li-ion
- Battery capacity: 12 volt 5,2 amps
- Light output duration:
  - 100%: 3 hours
  - 80%: 4 hours 20 min
  - 60%: 5 hours 40 min
  - 40%: 8 hours 20 min
  - 20%: 31 hours 55 min
- Dimmable: 5 steps
- Submersible: 300 feet
- Lens: 5 degree half angle
- Anodized Aerospace grade aluminium
- Grip: Thermo plastic rubber
- Strobe effect: 500 watts (non-lethal weapon)
- Pre-programmable: SOS or warning function
- Usable light: Range min. 1200 feet (1 lux)
- Signalling: 10 miles in clear weather
- Weight: 871 grams / 31 oz
- Size: Fronthead diameter 61 mm / 2.4"
- Body diameter: 44 mm / 1.7"
- Overall length: 25.5 cm / 10"
- Build in taillight
- Battery indicator
- Possibility to customize the functionality of the buttons and change the programming of the flashlight
- Build in antitheft chassis number
- Self-discharge time: 5 years



### CAUTION:

To extend battery lifetime adjust the power of the flashlight to your needs. When used with 100% power DO NOT leave unattended and use it (user serves as cooling device). Don't use the backend of the Tactical model for anything but charging.

### WARRANTY:

Guarantee conditions: You have a 2 year guarantee (limited guarantee for the batteries) if any problems arise with your WiseLED product. Return your WiseLED product to our address after which we will correct the problem as soon as possible or alternatively send you a new product. Vandalism, misuse or the like are not covered by the exchange rights. Enclose your receipt when exchanging the product. The warranty will become null and void if the product is misused, abused, tampered with or taken apart.

Visit [wiseled.com](http://wiseled.com) for more information